What else should you know?

- Before the first use make sure you wash the hookah for hygiene purposes.
- For your convenience, Watta 18 + hookahs have a temporary water level mark on the vase. Use it to remember the recommended water level, and then remove it.
- Use Watta WAT50108 disposable mouthpieces for the metal mouthpiece for personal hygiene.
- Use the additional WAT59145 set if you have lost the balls in the valve or to replace the grommets with new ones.

What is the warranty period?

Watta brand products are guaranteed for 18 months. The warranty period covers non-mechanical damage and manufacturing defects.

Where can I learn more?

Description, technical specifications, photos and video materials are available on the information portal watta.si

We hope that the use of the hookah will be comfortable and bring you a good mood:)

Diamond in d.o.o.

Znidarciceva uliva 7a 5290 Sempeter pri Gorici VAT ID: 97505226

All rights reserved







Assembly instructions and warranty obligations

Hookah Watta 18+ (for adults) made of stainless steel with a teal vase, silicone bowl, charcoal tongs (WAT19B29)



What is in the complete set?

Number according to the scheme	Name of WAT19B29 hookah components
WAT10998/1	Shaft of the Watta 18+ Mini
WAT10998/2	Hookah ashtray
WAT45164	Teal mini vase
WAT40119	Hose and hose spring
WAT40701	Hose mouthpiece
WAT40587	Black silicone bowl
WAT50105	Charcoal tongs
WAT50108	Disposable mouthpieces Watta
WAT59145	Additional set Watta

How to assemble?

STEP 1: unscrew the cone of the upper part of the shaft WAT10998/1, fit in the ashtray WAT10998/2 and screw the cone back; STEP 2: insert the assembled shaft into the vase WAT45164. If it is hard to insert the shaft into the vase, turn it clockwise;



Good job!